## Foil and Cut on Maxx, Maxx Air, Zing, and Zing Air from MTC

## By Sandy McCauley



May 25, 2019

A. Mat will remain in cutter between foiling and cutting (also refer to Section B)

1. Set up <b>Layers Bar</b> so that foil lines and cut lines are on separate layers. Rename them <i>Foil</i> and <i>Cut</i>	Foil Congress
2. Select <u>all</u> layers and move to a "rounded off position" (fewer decimal places for convenience)  Portrait mode: change the Y position	X: 2.0625 Y: 2.5000
Landscape mode: change the X position	Landscape x: 2.0000 Y: 2.5230
3. Select <u>ONLY</u> the <i>Cut</i> layer and change the position on the mat so that it is 0.03" (0.8 mm) offset from the <i>Foil</i> layer:  Portrait mode: add 0.03" (0.8 mm) to the <b>Y</b> position  Landscape mode: add 0.03" (0.8 mm) to the <b>X</b> position	X: 2.0625 Y: 2.5300 Portrait: increase Y  Landscape: increase X X: 2.0300 Y: 2.5230
4. Hide the <i>Cut</i> layer on the <b>Layers Bar</b> .	Foil  Congretion  Congretion
5. Go to the <b>Cut</b> window. Set <b>Cut Type</b> to <b>WYSIWYG</b> and turn off <b>Blade Offset.</b>	Blade Offset
6. Enter the force and speed settings that work best for FQ tip you're using. Set the origin and perform the foiling.	
7. After performing the foiling, hide the <i>Foil</i> layer and show the <i>Cut</i> layer.	Foil Congado
8. Without moving the cutting mat, remove the foil. (Note: Maxx, Maxx Air owners can press Offline on Control Panel, use arrows to move the mat for more convenient access for removing the foil, then press Online to return to origin).	
9. Switch out the FQ for the blade holder.	
10. Go to the <b>Cut</b> window. Enter the force and speed settings that work best for the material you're cutting. Restore the <b>Blade Offset</b> setting. Zing and Zing Air owners should choose <b>Use Last</b> in the <b>Set Origin</b> window to move to origin used for foiling.	Blade Offset Cut Type  WYSIWYG  Zing &  Zing Air  Knife Point WYSIWYG

B. Mat can be moved after foiling and before cutting using print and cut process in MTC. (Your KNK must be calibrated in MTC for PNC with current blade holder).

